

Ecolim® Filler Base



Product description

Waterborne Filler Base for mixing with wood dust, for filling gaps in parquet and hardwood floors.

Range of Use:

For small and medium gaps in parquet and hardwood floors of European and most exotic types of wood.

Features

- Fast drying
- Low smell
- Easy application
- Low 'after-sinking'
- Quick and easy to sand off
- Suitable for most wood types (tropical)

Technical Data

Article No.	10905	Application Rate	New installed parquet floor (with small/medium gaps)	approx. 10-20 m ² /L
Package Size	5L		Old floors with larger gaps	approx. 5-10 m ² /L
Packing	Box: 4 x 5L Pallet: 128 x 5L			
Solids	20 ± 1%	Application Tool	Stainless steel trowel	
Storage and Transportation	+5°C to +25°C (41°F to 77°F), storable for 12 months, not a hazardous material according to ADR	Drying Time	Sanding after 20-40 min* depending on size of gaps, humidity and temperature.	
GISCODE	W2+	Earliest time application	At least 1hr* before applying Ecolim Base Coat	
		Thinner	* NB! All drying times only apply at temperature of at least 18°C and a relative humidity of max 65%. Ecolim Filler Base is ready-to-use and shall not be diluted.	

Ecolim® Filler Base

Recommendations for filling gaps in parquet and hardwood floors:

1. Sand the floor with coarse and medium paper (ie. 36/40 and 60 grit)
2. Shake the can well
3. Mix **Ecolim Filler** with very fine wood dust from sanding (grit 100-120) into a smooth paste
4. Fill the joints using a stainless steel trowel
5. Let the floor dry for 20-40 minutes
6. Completely sand off all putty from area (final sanding with Grit 100-120)
7. Surface treat the floor with **Ecolim Base Coat** and/or Ecolim's topcoats (**2K Strike, 1K Star, 1K Nova** or **1K Eco**)
 - Regard safety regulations
 - Regard climatic conditions
 - Ventilate working area